

OPERATION & CARE INSTRUCTIONS

FOR THE

CHAMELEON/DAINTREE SCREEN SYSTEMS

TO RAISE THE BLIND

Lower blind from the locked position, just enough to release the tension. Turn centre lock anti clockwise to release the locking pins from the side channel.

Wind up blind to the centre locking position or all the way to the top.

- Whenever possible it is best to have the blind dry before winding up.

TO LOWER BLIND

Wind blind down to centre position, just below Blow Out Restrictor, or all the way down to the bottom, again just below Blow Out Restrictor ,leaving blind slightly loose. Now turn centre lock clockwise to release locking pins, then wind blind up till it is taught.

- Always make sure blind is under tension when in the locked down position.
- NEVER attempt to turn centre lock while blind is under tension.

CLEANING INSTRUCTIONS FOR CLEAR PVC

While clarity can be maintained (to some degree) with a cleaning regime, it is vitally important that all surfaces are not exposed to chemical compounds capable of damaging the PVC surface. Neutral diluted detergents are the most effective proven method of removing stains and marks off the surface of the PVC without affecting the structure or make up of the material.

RECOMMENDED CLEANING PROCESS:

1. Remove any particles on the surface of the material to avoid scratches when wiping with a clean cloth.
2. Clean with a soft fabric cloth using a diluted warm water based detergent solution 1:10 (1 part detergent 10 parts water).
3. Rinse completely with clean water and wipe dry with a soft lint free cloth or sponge.

While cleaning agents are commercially available for clear PVC materials it is important to verify the performance of such with the suggested cleaning instructions included and recommended by the cleaning solution manufacturer.

CLEANING INSTRUCTION FOR MESH FABRICS

- Remove dust with a vacuum cleaner or compressed air.
- Clean with a soft brush or sponge.
- Use water with mild detergent and soap flakes.
- Detergent ratio should be no more than 5 grams per litre of water.
- Rinse with clean water.
- Use warm water, do not use hot water.
- Do not scrub.
- Do not use solvents or any abrasive substance which might damage the coating of the fabrics.
- Leave the blind down until completely dry.